

Part List, Mechanical

Applicable for P1i and P1c









CONTENTS

1	General	2
2	Parts.....	3
3	Revision History	17











1 General

This Part List includes all parts possible to replace by using the Mechanical Repair Process.
Parts available to order will be found in the Web Shop.











2 Parts

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Antenna flex	Antenna flex	KRE 102 03	
		Screw M 1.6 x 4.0	Screw M 1.6 x 4.0	SXA 109 7094	
		Screw M 1.4 x 4	Screw M 1.4 x 4	SXK 109 5031	
		Keyboard support	Keyboard support	SXK 109 7176	









Parts continued



Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Label (KRH)	Label (KRH)	SVF 930 1450	
		System connector	System connector	RNV 799 36	
		Ear speaker holder	Ear speaker holder	SXA 109 7063	
		Microphone grommet	Microphone grommet	SXA 109 7319	
		Microphone gasket	Microphone gasket	SXA 109 7247	

Parts continued







Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		LCD gasket	Gasket LCD	SXA 109 6726	
		Dust gasket (system connector)	Dust gasket (system connector)	SXA 109 6165	
		Vibrator	Vibrator	BKE 902 019/27	
		BtB Flex (Mflex)	BtB Flex (Mflex)	ROA 219 5828	
		Flex Poron	BtB Flex Poron	SXA 109 7986	





Parts continued





Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Screw M 1.6 x 3.0	Screw M 1.6 x 3.0	SXA 109 7221	
		Liquid intrusion indicator	Liquid intrusion indicator	SXA 109 4884	
		Protective tape LCD	Protective tape LCD	SXA 109 5987	
		LCD	LCD	RNH 801 12	
		Touch panel	Touch panel	SXK 104 0313	



		Light guide	Light guide	SXX 104 0302	
---	---	-------------	-------------	--------------	--

Parts *continued*







Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Camera	Camera	KNC 201 40	
		Shielding box (camera)	Shielding box (camera)	SXA 109 7062	
		Shielding Lid (CIF camera)	Shielding Lid (CIF camera)	SXX 109 7222	



		Camera module	Camera module	KNC 201 41	
		CIF camera gasket	Gasket camera CIF	SXA 109 7251	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Flash flex	Flash flex ASM	SVF 930 0247	
		Ear speaker	Cyndi/Ear speaker AAC	RLE 908 24/3	




		Keyboard flex	Keyboard flex ASM	SXX 104 0246	
---	---	---------------	-------------------	--------------	--

Parts continued



Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Back key	Key, back	SXA 109 7628	
		Operator key	Key Operator	SXA 109 7629	
		Camera key	Key,Camera	SXA 109 7630	

		OnOff key	Key.OnOff	SXA 104 7631	
---	---	-----------	-----------	--------------	--

Parts continued



Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Cobrand plate	Cobrand plate,front	SXA 109 7607/1 P1i SXA 109 7607/3 P1c SXA 109 7607/12 VodaF SXA 109 7607/13 T mob SXA 109 7607/14 Swiss SXA 109 7607/15 A1 SXA 109 7607/19 O2 SXA 109 7607/22 Telefonica	

		Cobrand label	Cobrand label,back	SXK 109 7606/1 P1i SXA 109 7606/12 Voda SXA 109 7606/13 T Mob SXA 109 7606/15 A1 SXA 109 7606/18 CMCC SXA 109 7606/19 O2 SXA 109 7606/22 Telefonica	
		Cobrand Sticker	Cobrand Sticker	SXA 109 7604/1 generic SXA 109 7604/12 Vodaf SXA 109 7604/13 T Mob SXA 109 7604/18 CMCC	
		Antenna lid	Antenna lid asm	SXK 104 0292	
		Battery Lid Assy	Battery Lid Assy	SXK 104 0291	
		Pressure pad	Pressure Pad	SXA 109 8140	

		External antenna cap	External antenna cap	SXA 109 7616	
---	---	----------------------	----------------------	--------------	--







Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
------	------------------------	---------------------------------	---------------------	-------------	----------







		<p>Keyboard</p>	<p>Keyboard QWERTY Keyboard QWERTZ Keyboard AZERTY Keyboard, Cyrillic Keyboard, Chinese</p>	<p>SXA 109 7615/1 SXA 109 7615/2 SXA 109 7615/3 SXA 109 7615/4 SXA 109 7615/5</p>	
---	---	-----------------	---	---	--

Parts *continued*





Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
------	------------------------	---------------------------------	---------------------	-------------	----------

		Screw M 1,7x 6,5	Screw M 1,7x 6,5	SXA 109 5992	
		Front	Front asm	SXX 104 0293	
		Front	Front asm (2.5G version)	SXX 104 0293/101	
		Pen	PenStylus asm	SXX 104 0294	

Parts continued

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Frame	Frame asm	SXK 104 0296	Frame Without key's, Sub PCb asm, vibrator , antenna flex
		Loudspeaker gasket	Loudspeaker gasket	SXA 109 7200	
		LCD gasket	Gasket LCD	SXA 109 7856	

Parts continued

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Acoustic box	Acoustic box	SXX 104 0253	
		SUB PCB ASM	SUB PCB ASM	ROA 219 5830	

3 Revision History

Rev.	Date	Changes / Comments
A	2007-07-02	Initial release