

---

## 4. Array course control

---



**Test Jig (GH80-03307A)**



**Test Cable  
(0.4M:GH39-00930A, 1.5M:GH39-00928A)**



**RF Test Cable (GH39-00985A)**

## **Software Downloading**

### **4-1. Downloading Binary Files**

- 1) One binary files for downloading L870
  - onenand.img


### **4-2. Pre-requisite for Downloading**

- Downloader Program (LeTools v1.39)
- SGH-L870 Mobile Phone
- Data Cable
- Binary file


### 4-3. S/W Downloader Program

#### 4-3-1. Connection

- Connect SGH-L870 and JIG BOX
- Connect USB Port and UART port
- Reference the following feature




## 4-3-2. Download PGM




### 4-3-3. Usage of Downloader Tool(LeTools v1.39).


#### ① Run the LeTools




## ②. Select Rom image for downloading




③. Check the options(default, check only Format option)




④. Power on the phone with pressing the No1 + No4 key



## ⑤. Start Downloading



## ⑥.Completion




#### 4-3-4. Installation of USB Driver


- ① Select the installation in list or specific folder




- ② **Select to find proper driver in this folder. Selecting folder included USB driver**



③ Searching and installation.



- ④ If selection screen appears, Select *iboothostusb.inf* files



#### 4-3-5 keep this rules

1. If you connect USB cable through USB hub, sometimes downloading is failed.  
 ⇒ Try to connect USB cable to PC directly
2. Please **keep the sequence** for USAGE
3. Never **disconnect** during the downloading