



Part List, SP/Mechanical


Applicable for T630/T628


Contents

1	Exploded View T630	2
1.1	Exploded view Phone	2
1.2	Exploded view Frame	4
2	Part List T630	5
2.1	Part List Phone	5
2.2	Part List Frame	6
3	Part List Label	6
4	Revision History	7

1 Exploded View T630


1.1 Exploded view Phone







1.2 Exploded view Frame





2 Part List T630

2.1 Part List Phone

Contains mechanical parts.

Pos. number refers to the Exploded View.

Parts available to order will be found in the Web Shop.

Pos.	Description	Part Number	Comments
1	System Connector Solder Less	RNV 799 13	
2	Joystick Button Base	SXA 109 4506	
3	Dust Gasket for Joystick Button	SXA 109 4427	
4	Key Foil Assy.	SXK 109 5752	
5	Display (TFT).	SXK 109 5990	
6	Keyboard, Latin, WHITE	SXA 109 4509/1	
6	Keyboard, Arabic, WHITE	SXA 109 4509/2	
6	Keyboard, Chinese, WHITE	SXA 109 4509/3	
6	Keyboard, Hebrew, WHITE	SXA 109 4509/4	
6	Keyboard, Cyrillic, WHITE	SXA 109 4509/5	
6	Keyboard, Bopomofo, WHITE	SXA 109 4509/6	
6	Keyboard, Thai, WHITE	SXA 109 4509/7	
6	Keyboard, Hindi, WHITE	SXA 109 4509/8	
6	Keyboard, Latin, BLACK	SXA 109 4509/11	
6	Keyboard, Arabic, BLACK	SXA 109 4509/12	
6	Keyboard, Chinese, BLACK	SXA 109 4509/13	
6	Keyboard, Bopomofo, BLACK	SXA 109 4509/16	
6	Keyboard, Thai, BLACK	SXA 109 4509/17	
6	Keyboard, Hindi, BLACK	SXA 109 4509/18	
6	Keyboard, Latin, T-Mobile, BLACK	SXA 109 4509/19	
7	Front Assy. Cpl/White	SXK 109 5756/1Z	
7	Front Assy. Cpl/Black	SXK 109 5756/4Z	
8	Sound Channel Gasket	SXA 109 3006	
9	Frame	SXA 109 4510/xx	See 2.2 Part List Frame
10	Screw with Washer	SXA 109 3392	4 pieces
11	Antenna Assy.	SXK 109 4967	
12	Power On/Off key	SXA 109 4519	
12	Power On/Off Key, Black	SXA 109 4519/2	
13	Antenna Cover Assy. White	SXK 109 5758/1	
13	Antenna Cover Assy. BLACK	SXK 109 5758/4	
14	Camera Ring, White	SXA 109 4511	
14	Camera Ring, Black	SXA 109 4511/2	
15	Camera Module gasket	SXA 109 3013	
16	Plug (ext. antenna connector) White	SXA 109 4520	
16	Plug (ext. antenna connector) Black	SXA 109 4520/2	
17	Label Co-Brand, General	SVF 930 2283/	
17	Label Co-Brand, Orange	SVF 930 2283/3	
17	Label Co-Brand, Vodafone	SVF 930 2283/4	
17	Label Co-Brand, Telefonica	SVF 930 2283/5	
17	Label Co-Brand, WIND	SVF 930 2283/6	



Pos.	Description	Part Number	Comments
17	Label Co-Brand, O2	SVF 930 2283/7	
17	Label Co-Brand, TIM, White	SVF 930 2283/8	
17	Label, Co-Brand Blank, Black	SVF 930 2283/9	
17	Label, Co-Brand, Quickshare, Black	SVF 930 2283/11	
17	Label, Co-Brand Orange, Black	SVF 930 2283/13	
17	Label, Co-Brand T-Mobile, Black	SVF 930 2283/14	
17	Label, Co-Brand GoTone CMCC, White	SVF 930 2283/15	
17	Label, Co-Brand GoTone CMCC, Black	SVF 930 2283/16	
17	Label, Co-Brand TIM, Black	SVF 930 2283/17	
17	Label, Co-Brand Telefonica, Black	SVF 930 2283/20	
17	Label, Co-Brand Swisscom, White	SVF 930 2283/21	
17	Label, Co-Brand Swisscom, Black	SVF 930 2283/22	
17	Label, Co-Brand Vodafone, Black	SVF 930 2283/23	
18	Camera Module	SXK 109 5635	
19	ZIF Tape	SXA 214 6104	

2.2 Part List Frame

Pos.	Description	Part Number	Comments
1	Frame, White (Liquid silver)	SXA 109 4510	
1	Frame, Black	SXA 109 4510/4	
1	Frame, White (liquid silver), GMCC	SXA 109 4510/5	
1	T630/Frame/Black/T-Mobile	SXA 109 4510/6	
1	T630/Frame/White/T-Mobile	SXA 109 4510/7	
2	Battery Cover Cpl. White	SXK 109 5902/1	
2	Battery Cover Cpl. Black	SXK 109 5902/4	
3	Sim-Lock Lid	SXA 109 3008	
4	Speaker	RLE 907 17	
5	Speaker Gasket	SXA 109 2385	
6	Volume/Camera keys	SXA 109 4514	
7	Internet Access Key	SXA 109 2544	
7	T630/Internet Access Key/T-Mobile	SXA 109 2544/2	
8	Microphone Assy.	SXK 109 4962	
9	Vibrator	SXK 109 5217	
10	KRH-Label	SVF 930 361/1	

3 Part List Label

Pos	Description	Part Number	Comments
	KRH-Label	SVF 930 361/1	
	Printer Ribbon	LZK 102 734/1	

4 Revision History

Rev.	Date	Changes / Comments
A	2003-11-18	First release
B	2004-02-24	Black mechanical parts added
C	2004-03-18	Removed Label Co-Brand (SVF9302283/10, SVF9302283/2)
D	2004-04-02	Added Power On/Off Key, Black (SXA 109 4519/2)