

Part List, Mechanical

Applicable for Z555

Contents




1	General.....	2
1.1	View of Z555	2
2	Z555 Parts	3
3	Revision History.....	11



1 General





1.1 View of Z555











2 Z555 Parts



Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Upper Front Cover Assembly	Upper Front Cover Assy - Black	1206-9969	
			Upper Front Cover Assy - Rose	1207-0291	
			Upper Front Cover Assy - Sand	1207-0295	
		Antenna Assembly	Antenna assy - 850	1203-5814	
			Antenna assy - 900	1201-9343	
		Battery Cover	Battery Cover - Black	1201-9515	
			Battery Cover - Pink	1204-5813	
			Battery Cover – Sand	1206-2315	
		Camera	Camera - 1.3 MPixel	1200-8192	





Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Coax Cable Gasket	Antenna Tape	1204-5423	
		Ear Speaker	Ear Speaker - brown mesh	1206-6908	
			Ear Speaker - pink mesh	1206-6887	
			Ear Speaker - gold mesh	1207-5332	
		Hinge Plug cushion	Hinge Plug cushion	1202-1855	
		Flex Plug	Flex plug - Black	1201-9442	
			Flex plug - Pink	1204-5826	
			Flex plug - Sand	1206-2355	
		Hinge	Hinge	1200-9865	







Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Hinge FPC	Hinge FPC Assembly	1201-3575	
		Hinge Plug	Hinge plug - Black	1201-9441	
			Hinge plug - Pink	1204-5833	
			Hinge plug - Sand	1206-2358	
		Keyboard FPC Assembly	Keyboard FPC Assembly	1201-9331	




Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
 		Keyboard	Keyboard Arabic - Black	1204-6731	
			Keyboard Arabic – Pink	1204-6785	
			Keyboard Arabic – Sand	1206-2146	
			Keyboard Bopomofo - Black	1204-6772	
			Keyboard Bopomofo - Pink	1204-6784	
			Keyboard Bopomofo - Sand	1206-2147	
			Keyboard Cyrillic - Black	1204-6773	
			Keyboard Cyrillic - Pink	1204-6776	
			Keyboard Cyrillic - Sand	1206-2148	
			Keyboard Hebrew - Black	1206-2155	
			Keyboard Hebrew - Pink	1206-5154	
			Keyboard Hebrew - Sand	1206-2153	
			Keyboard Hindi - Black	1206-2161	
			Keyboard Hindi - Pink	1206-2160	
			Keyboard Hindi - Sand	1206-2159	
			Keyboard Latin - Black	1201-9499	
			Keyboard Latin - Pink	1204-5807	
			Keyboard Latin - Sand	1206-2145	
			Keyboard Latin Linear - Black	1204-6774	
			Keyboard Latin Linear - Pink	1204-6775	
			Keyboard Latin Linear - Sand	1206-2149	
			Keyboard Thai - Black	1206-2156	
			Keyboard Thai - Pink	1206-2157	
			Keyboard Thai - Sand	1206-2158	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Core Unit Label	Core Unit Label	1200-7792	
		Inner Frame Assembly	Inner Frame Assembly	1201-9540	
		Liquid Intrusion Indicator	Liquid Intrusion Indicator	SXA 109 4884	
		Loudspeaker	Loudspeaker	1202-0360	
		Lower Back Cover Assembly	Lower Rear Cover Assy - Black	1201-9459	
			Lower Rear Cover Assy - Pink	1204-5836	
			Lower Back Cover Assy - Sand	1206-2362	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Lower Front Cover Assembly	Lower front cover assy - Black	1201-9445	
			Lower front cover assy - Pink	1204-5824	
			Lower front cover assy - Sand	1206-2352	
		Lower Window Label	Cobrand Inlay assy - Black	1201-9497	
			Cobrand Inlay assy - Pink	1204-5810	
			Cobrand Inlay assy - Sand	1206-2306	
			Cobrand Inlay assy, MOVISTAR - Black	1207-5414	
			Cobrand Inlay assy, MOVISTAR - Pink	1207-5415	
			Cobrand Inlay assy, MOVISTAR - Sand	1207-5417	
			Cobrand Inlay assy, VIRGIN - Black	1207-5410	
			Cobrand Inlay assy, VIRGIN - Pink	1207-5411	
			Cobrand Inlay assy, VIRGIN - Sand	1207-5412	
		Upper Window Label	Upper front upper screw cover assembly-Black	1201-9496	
			Upper front upper screw cover assembly-Pink	1204-5809	
			Upper front upper screw cover assembly-Sand	1206-2304	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		5IP screw	Screw - 5IP - 1.6X4	1200-9961	
		Lower Rear Screw Cover	Lower Rear Screw Cover assembly -Black	1202-0296	
			Lower Rear Screw Cover assembly -Pink	1204-5812	
			Lower Rear Screw Cover assembly -Sand	1206-2307	
		SIM/M2 Flex	SIM/M2 FPC Assembly	1201-9311	
		Outer Display Adhesive	Sub Display Adhesive	1202-1857	
		System Connector Gasket	System Connector Gasket	1202-7371	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Upper Back Cover Assembly	Upper Rear Cover Assy - Black	1201-9502	
			Upper Back Cover Assy - Pink	1204-5815	
			Upper Back Cover Assy - Sand	1206-2318	
		Upper PBA	Upper PBA	1201-3567	
		Vibrator	Vibrator	1200-8802	
		Vibrator Clip	Vibrator Clip	1204-5422	
		Volume Key	Volume Key - Black	1202-0294	
			Volume Key - Pink	1204-5835	
			Volume Key - Sand	1206-2360	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Hinge Flex Adhesive	Hinge Flex Camera Adhesive	1203-4164	
		Upper PBA adhesive	Upper PBA adhesive	1202-5565	

3 Revision History

Rev.	Date	Changes / Comments
1	Mar. 24, 2008	Initial Release