# The Samsung E810 Quick Start guide

In just a few minutes we'll show you how easy it is to use the advanced features of your new Samsung E810 (customised for Vodafone live!).

You'll see how quickly you can take pictures and video clips with its built-in digital camera, send photos and sounds in MMS messages, and connect to Vodafone live!. You'll also be able to personalise your phone by simply downloading new ringtones, games and wallpapers.

Getting started

1. Insert your SIM card:
Slide your Vodafone SIM card into its slot, making sure that the gold contacts of the SIM are facing down, and the cut-off edge is correctly aligned.

2. Insert the battery:
Insert the battery (gold contact edge first), and push it down until it clicks shut. The battery may need charging (a full charge can take up to 4 hours).

3. Turn it on:
Press and hold the red 🔴 key. (Do the same to turn it off again.)

1. The phone

Keys and navigation

Headphone socket

Volume keys

Left soft key: selects whatever option is displayed in the bottom left of the screen (usually **Select**). In standby mode it opens **Messages**.

Right soft key: selects whatever option is displayed in the bottom right of the screen (usually **Back**). In standby mode it opens **Vodafone live!**.

Navigation key: press to OK an action or select whatever option is highlighted. In standby mode it opens the main **Menu**.

Move the navigation key sideways to move around icons and menu lists. In standby mode, up starts the **Camera**, right opens **Calendar**, down opens **Contacts** and left opens **My items**.

Call key: Press to answer a call (or open the slider). In standby mode it opens the **Calls** list.

End key: Press to end a call (or close the slider). Press and hold to turn on and off. Press to return to standby mode.

Clear key: press to delete a character of text. Press and hold to delete all text.

Volume keys: press to change call volume.

2. The camera

With the built-in digital zoom camera it's easy to take photos and video clips. Photos can be sent to other people as a picture message (see Section 3).

Take a photo

1. Turn on the camera:
In standby mode, press and hold the **Camera key** [ ] on the side of the phone, or press the navigation key up.

2. Take the photo:
Rotate the lens to point in the right direction, then press the key (or press the camera key again) to take the photo. To discard it, press [Cancel].

Tips: In viewfinder mode, press ▲ and ▼ to zoom in or out, and ◄ and ► to adjust the brightness. Press the volume key up to flip the picture upside down, and down to flip it left to right. Press to adjust the settings.

3. Save your photo:
Press [Save]. It's saved in the **My photos** folder, found in **My items/ Pictures** in the main **Menu**. Press [Back] to take another photo, or press [Options]. Choose **Send MMS** to send it as a picture message, or **Set as wallpaper** to use it as your screen background. **Set as caller ID** adds it to a contact detail so it will appear when they call.

Rotating lens

Take a video clip

1. Take a video clip:
In standby mode, go to **Menu/Camera/Record video** (or in camera viewfinder mode, press **1**). Press [ ] to start recording, then press it again to stop. Press [Save] (it's saved in **My items/My videos**), or press [Back] to discard it.

2. View your video clip:
Go to **Camera/My videos** to view your clips (press [ ] to play).

Tips: You can use the same adjustments as in Camera mode. You can save up to 5 video clips, regardless of length (until you run out of memory).

3. Picture messaging

*With multimedia messaging (MMS) you don't have to just send a text
message. Now it's just as simple to send pictures and sounds as well!
Your E810 is already enabled to send and receive MMS.*

Create and send a new multimedia message

1. Start a new message:
In standby mode, press [...] [✉]. Select **Create message**, and
then **MMS**.

2. Enter a subject (optional):
Enter a subject (title) for your message, then press ⬜, or just press
⬜ to go straight to the Add screen.

3. Enter the text:
Press ⬜ twice (or select [Options]/**Add text**) and write your message,
then press ⬜ to return to the message screen.

Text tips: The Hash key #⤢ adds a space, the **1** key cycles through
punctuation, and the Star key *⤢ cycles between upper case, lower
case, numbers and symbols. Pressing and holding the Star key turns
predictive text (T9) on and off.

4. Add a photo:
Press ⬜ twice (or [Options]/**Add photo**). Choose **Take photo** to take
a new photo, or **My photos** to choose a saved one. Press ⬜.

5. Add a sound clip:
Press ⬜ twice again, and choose **Record new** to record and save
a new sound clip (this uses the **Voice recorder** in the **Applications**
folder. Sounds are saved in **My sounds**). Press ⬜.

6. Preview your message:
Press [Options]/**Preview** to see (and hear) your message. Press [OK],
then [Back]. (To change any part of your message, highlight it with the
navigation key, then press [Options]/**Edit...**)

Messages	12 Apr
1 Create message	
2 Inbox	
3 My messages	
4 Call voicemail	
5 live! Studio	
6 Vodafone mail	
Select	Back

Hey there	12 Apr
Wait till you see this!	
Add here	
Page 1/Øk	
Options	Back

Wait till you see this!

OK

7. Send your message:
Press [Options]/**Send message**, then select **To(Ø):**. To send it to a mobile choose **Phone number**, and enter the number. Choose **E-mail address** to send it to an email address. Or choose **Contacts list** to choose a number or email address from your Contacts. Then press ⬤ twice to send it.

Multimedia messaging tips

1. Adding pages: In the Add screen, move the highlight from **Add here** to **Page 1/...** and select [Options]/**Add page**. You can now add more text, pictures and sounds to your message.

2. Sending to a mobile: Try sending one to yourself to see how it works. Note that if you send a message to a phone that isn't picture message compatible, they'll be sent a web address to view it on.

3. Sending to more than one person: To send your message to more than one person, select **Add contacts** in the **To** menu..

4. Vodafone *live!*

Vodafone live! brings your mobile to life: full of information, downloads, games, music and services. It's easy to use, and the connection can be 'always on' so there's no wait for dialling up.

Connect to ⭕ vodafone *live!*

In standby mode, press [...] [**⭕live!**] to connect you to the **Vodafone live!** main menu. To exit, press and hold the key.

It works very like an ordinary web browser. Simply highlight the item you want to select, then press the key to open that page.

Press [Back] to go back a page. Press and hold for the Browser **Menu setting** menu.

Vodafone *live!* links

You can also link directly to the Vodafone *live!* service you want using your phone's built-in links.

1. Links:
Go to **Menu/Vodafone live!**. This page is offline, so you won't be connected until you choose a link. Here are some of the services you can choose:

Vodafone live!: connect to the Vodafone *live!* home page.
What's new: what's new in Vodafone *live!*.
Games: download games for your E810.
Ringtones: download sounds and ringtones.
Pictures: download images, animations and background wallpaper.
News: get the latest news reports and weather forecasts...

Tip: Vodafone *live!* is growing and changing all the time, so the options may vary. Keep checking it out to see what's new.

2. Bookmarks:
Go to **Menu/Vodafone live!/Bookmarks** to find **Sport** (the latest scores, results and news), as well as space to store your own favourite bookmarks.

5. Downloads

Change your E810 whenever you want by downloading new polyphonic ringtones, games and background wallpaper from Vodafone live!.

Download more

1. Download a new ringtone:
Go to **Menu/My items/Sounds** and choose **Download more**. Choose the ringtone and follow the instructions to download it. To activate your ringtone, go to **My items/Sounds**/**Saved sounds**. Highlight your downloaded ringtone and select [Options]/**Set as ringtone**.

2. Download new background wallpaper:
To choose a new background image for your phone, go to **My items/Pictures**/**Download more**. Choose the image you'd like and follow the instructions to download it. Then go to **My items/Pictures/Saved pictures**, select your downloaded image and choose [Options]/**Set as wallpaper**.

3. Download new games:
To add more high quality games to your handset, select **My items/Games/Download more**. Choose a game to download, and you'll find it in **My items/Games/Saved games** (there are some great games there already).

6. Other services

Now you can use your phone to send a postcard, or send pictures to an online album.

Postcard and live! Studio

1. Postcard:
Now you can send a photo from your handset as an actual postcard. Go to **Messages/Create message/Postcard**, and add a picture, text and the address. Press [Options]/**Send**. Vodafone will have it printed on a postcard and sent by mail. (Note: the Postcard service is not available in every country.)

2. live! Studio (may also be called Media Album):
Now you can send selected pictures to an online album (part of Vodafone *live!*) where you and your friends can access them remotely. Check with your local Vodafone service provider for details.

7. Other functions

Here are a few other functions for your new phone. There's much more information in the manual – or you could just explore all the menus and options screens...

Phone hints

1. Silent mode:
To go into Silent mode, press and hold the ⌨ key in standby mode (you'll see an icon at the top of the screen and feel the phone vibrate). Do the same to restore your ring volume.

2. Phone lock:
To lock the phone, simply slide the keypad shut. When the **Keypad locked** sign appears the keys will be locked until you slide the keyboard open again.

3. Camera light:
Your E810 has a camera light at the back (you can only see it with the slider open). Normally, it comes on automatically when you take a shot in low light. To turn it on manually, press ⌨ [Options]/**Settings**/**Flash light**/**Manual** (when the camera is active). You will now be able to turn the light on and off by pressing the **0** key (only in camera mode).

4. Alarms:
Go to **Menu/Applications/Alarms** for a variety of alarm functions. **Morning call** is a repeating alarm for the weekdays (Mon-Fri or Mon-Sat), while setting **Autopower** to **Enabled** will make the alarm ring even when the phone is turned off.